


ASSEMBLY INSTRUCTION


DE - MONTAGEANWEISUNG
FR - INSTRUCTIONS DE MONTAGE
DK - MONTAGEVEJLEDNING
CZ - NÁVOD K MONTÁŽI
ES - INSTRUCCIONES DE MONTAJE
FI - ASENNUSOHJE

HR - UPUTE ZA MONTAŽU
SE - MONTERINGSANVISNING
SI - NAVODILA ZA MONTAŽO
TR - MONTAJ TALIMATI
NO - MONTASJEANVISNING
IT - ISTRUZIONI DI MONTAGGIO

GR - ΟΔΗΓΙΑ ΣΥΝΑΡΜΟΛΟΓΗΣΗΣ
NL - MONTAGE INSTRUCTIE
PT - INSTRUÇÕES DE MONTAGEM
PL - INSTRUKCJA MONTAŻU
HU - SZERELÉSI UTASÍTÁS




20 min




0 cm
1
2
3
4
5
6
7
8
9
10
11
12
13
14


- | | | |
|---|-----|---------------------------|
| ① | x 8 | HW-ST-01-078
(7 x 120) |
| ② | x 2 | HW-ST-01-046
(7 x 90) |
| ③ | x 3 | HW-ST-01-043
(7 x 65) |
| ④ | x 4 | HW-ST-01-040
(7 x 50) |
| ⑤ | x 4 | HW-WD-17-011
(10x40) |
| ⑥ | x 1 | HW-ST-18-001
(4 x 98) |




(A) x1




(B) x2



(C) x2



(D) x1



(E) x1

