
Care and Maintenance on Painted Wood Outdoor Furniture

Characteristics

Always make certain to cover your outdoor wood furniture with waterproof covers when you are not using it. Although it may seem as a lot of work, placing covers only takes few minutes and will protect your furniture from the elements. The sun is also another factor that can damage your furniture and covering it protects it as well.

All timber surfaces will change colour and mellow over time. New furniture will initially vary in shade from items that have been previously purchased.

Clean product with appropriate material to retain a good level of protection.

Care and clean guidance

Please clean the furniture with a soft cloth and a dilute soap solution

Rinse it with water and let it dry thoroughly.

Caution:

Do not use pressure cleaning machines or you will damage the structure of the wood.

Obstinate dirt can be removed by applying more pressure when cleaning with soft cloth.

Afterwards please polish the surface with a soft cotton cloth.

For a more intensive treatment, you will need to paint the wood once or twice.

Always paint "wet on wet", i.e., allow the oil to soak in.

Do not let the wood dry before you apply the next coat.

Let the furniture get dry for at least 48 hours before using it again.

Safety

Due to the expansion and contraction of the wood caused by weather, we recommend retightening all of the hardware two weeks after assembly. Periodic checking of all connections and hardware is also advised.

With care and attention your product will give you many years of enjoyment!

PLEASE KEEP THESE INSTRUCTIONS FOR FUTURE REFERENCE