





ASSEMBLY INSTRUCTION

24"H SWIVEL COUNTER HEIGHT CHAIR 29"H SWIVEL BAR HEIGHT CHAIR


A Backrest	B Cushion Seat	C Footrest	D Apron With Swivel Plate	E Chair Leg
				
1pc	1pc	1pc	1pc	4pcs
F Bolt 1/4" x 1-3/8"	G Bolt 1/4" x 1-3/4"	H Lock Washer 1/4" x 1/2"	I Flat Washer 1/4" x 1/2"	J Flat Washer 1/4" x 5/8"
				
16pcs	6pcs	18pcs	12pcs	10pcs
K Allen Wrench 5/32" (Long)				
				
1pc				



This page lists all the contents included in the box. Please take the time to identify the hardware as well as the individual components to this product. As you unpack and prepare for assembly, place the contents on a carpeted or padded area to protect them from damage.

1


Attach the Chair Leg (E) to the Apron With Swivel Plate (D), then attach the Footrest (C) to the Chair Leg (E). Use Bolt (F), Lock Washer (H), Flat Washer (I) with Allen Wrench (K) for both.




Take the Allen Wrench, and turn the bolts until the legs are secured. **DO NOT TIGHTEN COMPLETELY.** Stop when you feel you are adding force to tighten the bolt.

2

Invert Cushion Seat (B) and place on a stable raised surface (i.e. Table). Attach the Backrest (A) to the Cushion Seat (B) using Bolt (G), Lock Washer (H), Flat Washer (J) with Allen Wrench (K).

**3**

Keep the Backrest (A) and Cushion Seat (B) inverted on a stable raised surface. Attach the Swivel Plate located on the Apron With Swivel Plate (D) to the Cushion Seat (B) using Bolt (F), Flat Washer (J) with Allen Wrench (K). Turn the Swivel Pub Stool right side up.



Stand chair up on an even surface and check that it is balanced. If there is a slight wobble, apply downward pressure in the corner where a leg is uneven. Keeping pressure in that corner, tighten all bolts. If balanced, apply downward pressure evenly in the center and tighten all bolts. Do not over-tighten beyond hole depth.

Helpful Tip:

-Instead of applying downward pressure while reaching under to tighten bolts, have someone sit in the chair while you tighten the bolts.

CLEANING & CARE

Treat surface with care. Surface is resistant to scratches but is not scratch resistant. Clean surface with a dry or damp soft cloth. Do not use abrasive cleaners. Hardware may loosen over time. Periodically check that all connections are tight.