

TABLE ASSEMBLY INSTRUCTIONS

1. PLACE TOP UPSIDE DOWN ON CARPETED FLOOR OR BLANKET.
2. TURN SIDE UPSIDE DOWN AND SLIDE METAL BRACKETS OF SIDE INTO METAL BRACKETS OF TOP.
3. REPEAT WITH OTHER SIDE.
4. CAREFULLY TURN TABLE RIGHT SIDE UP AND GENTLY BUT FIRMLY PUSH DOWN ON TOP TO LOCK BRACKETS INTO PLACE.

