

INSTRUCTIONS FOR BED

- 1) Hold up Headboard.
- 2) Hold up Footboard.
- 3) Insert one end of side rail into front of head board.
- 4) Insert one end of side rail into front of foot board.
- 5) Tighten the nuts on the bolts on each side to steady it.
- 6) Repeat for other side of bed.
- 7) Place lengthwise Center Board at Head and Footboard in premade slot.
- 8) Place 7 side slats across center board widthwise in pre-made slots.

Your bed is now ready for a mattress and box spring.