10 YEAR MANUFACTURER'S LIMITED WARRANTY


All parts of this Elements Of Design faucet are warranted to the original retail purchaser to be free from defects in material and workmanship for a period of ten(I0) years from the date of purchase as shown on the purchaser's receipt. This warranty is limited to defective parts only, labor charges and/or damage resulting from improper installation, repair or replacements, as well as incidental and consequential damages connected therewith are excluded.

Any damage to this faucet as a result of misuse, abuse, neglect, accident for improper installation or any use not consistent with the instructions furnished by Elements of Design, will void this warranty. Replacement parts can be obtained from your local dealer.

CAUTION!!!

- Water lines must be completely flushed before use, to avoid bris & clogs in your water system leading to malfunction and reduction of water flow.
- 2. Warranty to be void if water lines are not flushed before use of new faucet.
- 3. Use of abrasives of any strength may damage the finish of your faucet and void this warranty.


CODE APPROVAL: LA#M-000018






T 909.465.6687 F 909.548.6843 1877.FAUCET.1 www.eodfaucet.com email: support@eodfaucet.com


INSTALLATION SHEET




1. Shut off hot and cold water supply under sink. Plug sink drain with cloth to avoid losing small parts. Remove old faucet.



2. Install new faucet spout through the center hole of sink. Place mounting washer on spout shank and attach with spout shank locknut.





5. Connect the flexible tubes from the supply shank side port to the Spout Tee. Also reattach the supply lines, turn on the water supply, and check for leaks.




6. turning on your new faucet for the first time.

Allow both hot and cold water to run for one minute.





3. Attach Spout Tee on the spout shank.



4. Hold the handles in proper position. Make sure that the top of the faucet handles is 5/8" above the top of the sink. Mount the metal washer and locknut from underneath the sink. Than reposition escutcheons as necessary to a desired height.

Lever Handles Alien wrench Screw broache CHOSS Handles Cap Screw Handle broache

ASSEMBLY INSTRUCTIONS FOR HANDLES

Lever Handles:

1. Put the lever handles on the broaches and Tighten using the alien wrench provided.

CHOSS Handles:

- 1. Remove the insert caps from the cross Handles.
- 2. Put the cross handles on the broaches and Then tighten the screws. Insert the caps on The cross handles.

Copy Rights: 2004 Elements Of Design