



How to attach a David Francis Furniture headboard to a bed frame

You will need the following:

- **Drill**
- **Standard, 1/4" drill bit**
- **(4) – 2" long, 1/4" thick bolts**
- **(8) washers**
- **(4) wing nuts**

Attachment Instructions:

- 1. Place the metal bedframe against the headboard**
- 2. Use a pencil to mark the holes on the bedframe (two on each leg)**
- 3. Remove the bed frame and set aside**
- 4. Using a standard 1/4" drill bit, drill into the 4 pencil marks on the headboard legs**
- 5. Place the bed frame against the newly drilled holes**
- 6. Insert the washers into the bolts**
- 7. Insert the bolts through the bed frame and into the headboard legs**
- 8. Secure with the wing nuts**

As an alternative, these headboards can be mounted/hung on the wall.