# **Coat Hooks with Storage**



Thank you for purchasing our Coat Hooks with Storage. Assembly of this product requires a screwdriver. We have found it helpful to have a second person present in at least one step of the assembly.

# **Coat Hooks with Storage Assembly Instructions**

Lay out all parts on a "non-abrasive" surface to avoid scratching furniture.

NO.	Drawing	Description	Qty.
A	<u>.</u>	Hooks	1
В	( <u></u> j	French Cleat	1
С	f <del>o nama</del> s	Wood Screws	4

## PARTS

## Step 1

Read through these instructions thoroughly before beginning assembly. We have found this to be of great value when first assembling this product.

# Step 2

Remove all parts and hardware from packing material. Wooden pieces should be placed on a non abrasive surface (like the carton or carpet) to prevent damage to the finish. Note the French Cleat (B) is pre-installed on the back of the Hooks (A) with 2 of the Wood Screws (C).

# Step 3

Remove the French Cleat (B) from the back of the Hooks (A) by unscrweing 2 of the pre-installed Wood Screws (C). on the top of the Hooks (A). Locate studs behind drywall in desired location. Attach French Cleat (B) to wall studs with 2 Wood Screws (C).





#### CARE

Clean with mild soap and wipe dry.

# **REPLACEMENT PARTS**

Please do not contact the company you purchased from as we can help you faster.