## ASSEMBLY INSTRUCTIONS

1nc

Inc

3pcs

Thank you for purchasing this quality product. Be sure to check all packaging material carefully for small parts that may have come loose inside the carton during shipment.

"Hardware is attached underneath the seat bottom"

## Components List:

A. Back Frame	
B. Seat Frame	









## Hardware List -







Reminden

1. Use only the hardware supplied. 2. Once the chair is finished, level and tighten all the bolts.

3. Do not over-tighten balts.

4. This item may require periodic tightening.

NOTE: Hardware pack is located underneath the seat frame (B)

Step1: Attach the seat frame (B) to Back frame (A) by

using flat washer (7), spring washer (6) and bolt (3&4).

Step2: Attach Left and Right Side Rails (F&G) to Back frame(A) using Wood Screws (8) through pre-drilled holes of Side Rails (F&G) and

Back frame (A), Assemble Front Rail (E) to Front Legs (C&D) using Wood Screw (8), Attach the assembled Front Lee (C&D) and Front Rail (E) to Seat Frame (B) by using tlat washers(7), spring washers (6) and hex-nut(5). Attach Front Legs (C&D) to the Left and Right Side Rails (F&G) using Wood Screws (8) through pre-drilled holes on the Left and Right Side Rails (F&G).

Assembly is now complete

Thank you for choosing this product.





