## ASSEMBLY INSTRUCTIONS Made in China Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts which may have come loose inside the carton during shipment. Separate, identify, and count all parts and metal hardware. Compare with parts list to be sure all parts are present. If any part(s) are missing or damaged, phone, fax, or mail to our Customer Service Department. For efficient and speedy service, please indicate the model number and code letter of part(s) needed. PARTS (A) LEFT SIDE PANEL SHORT CROSS BARS (3) (Q) HANDLES (3) (I) **RIGHT SIDE PANEL** MAGAZINE CROSS BAR (R) PULL (B) (J) FRONT CROSS BAR CAM-BOLTS (8) (C) DIVIDER (K) (S) BASE (D) (L) SHELF CAM-LOCKS (8) (T) TOP SMALL DOWELS (12) COVERS (4) (E) (M) (U) BACK LARGE DOWELS (20) SHELF SUPPORTS (4) (F) (N) (V) (G) DOOR HINGE PINS (2) BACK CROSS BAR (O) (W) MACHINE SCREWS (6) (H) TRAY (P) HARDWARE ILLUSTRATIONS Tools required: Screwdiiver R ລ ATTENTION: SOME NUMBERED PARTS LISTED ON THE INSTRUCTION SHEET MAY NOT BE IN PARTS BAG AS THEY MAY ALREADY BE ASSEMBLED. CAREFULLY CHECK PARTS

**IMPORTANT NOTE:** Follow instructions listed below in the proper sequence as numbered to assure fast, easy and correct assembly.

- 1. **Note:** Upon opening, thoroughly clean all wood surfaces with furniture polish to remove dust and dirt that may have settled onto finish during shipment.
- Place parts on a soft cloth. Insert Large Dowels (N) into bottom of Divider (C). Insert Small Dowels (M) into ends of Short Cross Bars (I). Insert Dowels (M,N) extending from Divider (C) and Short Cross Bars (I) into top of Base (D). Insert Dowels (M,N) extending from top of Short Cross Bars (I) into Magazine Cross Bar (J). (See ill. #1)
- 3. Insert Large Dowels (N) into ends of Magazine Cross Bar (J) and Front and Back Cross Bars (K,W), Tighten Cam-bolts (S) into threaded holes in Left and Right Side Panels (A,B). Insert Dowels (N) extending from Front and Back Cross Bars (K,W) and Magazine Cross Bar (J) into Side Panels (A,B) while inserting Cam-bolts (S) extending from Side Panels (A,B) into sides of Base (D). Insert Hinge Pins (O) into top and bottom corners of Door (G). Insert Hinge Pins (O) extending from Door (G) into top of Base (D) and underside of Front Cross Bar (K). Insert Dowels (N) through Front and Back Cross Bars (K,W) and into top of Divider (C). Insert Cam-locks (T) into holes on underside of Base (D) with slot for screwdriver facing outward. Rotate Cam-locks (T) clockwise to secure Cam-bolts (S). Insert Machine Screws (P) through Door (G) and tighten into Handles (Q). NOTE: Front Cross Bar (K) has latches on underside. (See ill. #2)

AND PACKING MATERIALS PRIOR TO ORDERING REPLACEMENTS.

Slide Back (F) into groove between Side Panels (A,B). (See ill. #3)





If you have a problem, we want to have the opportunity to make it right!

	any problems can be resolv		TTO THE STORE roduct to the retailer)	
FAX this form to us or call Customer Service Have your model number and part code letter handy.			Name	
			Address	
Have your r	noder number and pair		Daytime Phone ( )	
Have your r	Description	Quantity	Daytime Phone )   Reason for Replacement	
Part Letter	Description	Quantity		