# **ALIGN<sup>™</sup>** Technical Specification

## **Swiveling Double Robe Hook**

#### YB0402

### **Stock Numbers:**

- YB0402CH Swiveling Double **Robe Hook Chrome Finish**
- □ YB0402BN Swiveling Double **Robe Hook Brushed Nickel Finish**
- □ YB0402BL Swiveling Double Robe Hook Matte Black Finish



#### **Materials:**

Swiveling Double Robe Hook is constructed of zinc.



Buy it for looks. Buy it for life.®

#### **Installation Instructions:**

Note: Directions below are for installation into drywall. If installing product into a stud, use the wood screws only.

- 1 Remove mounting posts from the product assemblies by loosening each setscrew.
- 2 Position the mounting plate on the wall in the desired location and mark holes at the Horizontal screw location on the template if installing into drywall or vertical screw location if installing into a stud.
- 3 Drill 1/4" pilot holes in marked locations.
- 4 Lightly tap anchors until flush with the wall.
- 5 Place each mounting plate over anchors and insert screws through post into anchors.
- 6 Tighten screws.
- 7 Place posts over the mounting plates with setscrew facing down and tighten setscrew.

### **Cleaning Instructions:**

To preserve the fine finish of this product, clean only with a soft damp cloth. Dry well. Do not use commercial or abrasive cleaners.

Stock Number: **Robe Hook By MOEN**  \_YB0402 Swiveling Double

25300 AL MOEN DRIVE • NORTH OLMSTED, OH 44070 CORPORATE HEADQUARTERS: (800) 321-8809 • FAX: (800) 848-6636 INTERNATIONAL: (440) 962-2000 • FAX: (440) 962-2726 CUSTOMER SERVICE (USA): (800) 882-0116 • FAX: (888) 379-2720 WWW.MOEN.COM ©Copyright Moen, Inc.