©2012 SONNEMAN - A WAY OF LIGHT



Important: Always disconnect the power before installing or replacing bulb and before cleaning or other maintenance.

LAMP INSTALLATION AND ASSEMBLY

- 1. Attach mounting plate to the wall using wood screws and anchors.
- 2. Screw together the (2) 12" stem, and screw it to the hole on the bottom of back plate.
- 3. Attach back plate to mounting plate. Tighten with back plate screws.
- 4. Install 75W G9 Xenon bulb. (included)
- 4. Attach the explosion guard to the socket cup, and secure with screw.
- 5. Plug in the cord and the high-low-off switch is located on shade holder.

CARE INSTRUCTIONS

Dusting — Use a clean, dry cloth. Cleaning — To protect the finish, shade holder avoid any harsh abrasives or chemicals. back plate screw mounting plate **G9** Xenon bulb 1 anchor back plate wood screw socket cúp screw explosion guard (2) 12" stem