

HEADBOARD BRACKET INSTALLATION GUIDE

Tools:

To install your headboard brackets you will need the following tools:

- 9/16" socket and crescent wrench
- 1/2" socket and crescent wrench

Contents:

- A. (2) Headboard Brackets
- B. (2) Attachment Plates
- C. (2) Plastic Spacers
- D. (8) Long Bolts 9/16"
- E. (10) Short bolts 9/16"
- F. (18) Nyloc Nuts 1/2"

STEP 1:

a) Align the hole in the bracket to the brass sleeve into which the leg threads. Hold the bracket in place and screw the leg into the base until it is snug. **DO NOT OVERTIGHTEN.** Too much force may cause the leg to spin freely.

b) The headboard bracket will have 2 tabs to accommodate any frame type. Align the appropriate tab on the bracket with the hole on the base. Use a short bolt and nut to secure the bracket. Make sure the bolt is tight.

STEP 2:

Attach the plastic spacer and T-Bracket.

a) Measure the distance between the mounting holes on the headboard and install the spacer and attachment plate to accommodate the headboard.

b) To install the plastic spacer and attachment plate, you will need (2) long bolts and (2) nuts. Place the spacer and attachment plate in the desired location and slip the bolts through the holes with the head of the bolt facing outward. Position the bolts diagonally on the spacer. Use the 9/16" socket and wrench to tighten the bolts.

Step 3:

You may now connect your headboard to the attachment plates using the remaining short bolts and nuts to secure it to the brackets. The heads of the bolts will face outward. Use a 9/16" socket and 1/2" wrench to tighten the bolts.

