Chair Information Guide



Pneumatic Seat Height Adjustment

-Allows quick and easy adjustment

-Regulates height of the chair relative to the floor



2-to-1 Synchro Tilt

- Tilt lock out and adjustable tilt tensions

- Allows users to recline while keeping the seat cushion relatively level to the floor




Tilt Tension

- Controls rate and ease with which the chair reclines for different weights and strengths of users.

#1. Synchro Tilt Lever - to lock chair in upright position push the lever in, and to unlock pull the lever out

#2. Seat Height Adjustment – apply pressure to the seat and lift lever for height to decrease, remove pressure to the seat and lift lever for height to increase

#3. Tilt Tension – turn clock-wise to intense tension and reduce tilt, turn counter clock-wise to decrease tension and allow more tilt



Device Beneath Seat