

ASSEMBLY INSTRUCTION


TUFTED ACCENT CHAIR






This page lists all the contents included in the box. Please take the time to identify the hardware as well as the individual components to this product. As you unpack and prepare for assembly, place the contents on a carpeted or padded area to protect them from damage.

Put the chair(A) on a smooth flat surface, attached the two front legs(B) to the chair(A) use bolt(H), lock washer(F) and flat washer(G) on both of chair. Turn the allen wrench(D) in bolt(H). But not too tight.



Put the chair(A) on a smooth flat surface, attached the two back legs(C) to the chair(A) use bolt(E), lock washer(F) and flat washer(G) on both of chair. Turn the allen wrench(D) in bolt(E). But not too tight.



-Instead of applying downward pressure while reaching under to tighten bolts, have someone sit in the chair while you tighten

Cleaning & Care

over-tighten beyond hole depth.

Treat surface with care. Surface is resistant to scratches but is not scratch resistant. Clean surfaces with a dry or damp soft cloth. Do not use abrasive cleaners. Hardware may loosen over time. Periodically check that all connections are tight.