
Assembly Instructions



Congratulations on your latest purchase.

Now what? Don't start sweating over this box of parts. This will be easy. We did the hard work for you. All you need to do is follow our simple instructions and you'll be on your way to transforming your room in no time. Good luck --though we're confident you won't need it.

Before you begin


1. Check for damaged or missing parts. Customers can email or call us to order missing supplies.

- 2. Use the carton as a working surface to prevent product damage during assembly.
- 3. Gather all tools prior to assembly.

Table of contents


introduction	2
hardware	4
parts list	5
assembly	6 - 10

Hardware




ITEM DESCRIPTION QUANTITY

1	chair back	1
2	seat cushion	1
3	front leg	2



step 1.



Please do not assemble with power tools


step 2. Do not tighten the bolt until the next step. 2 1 (2) Ε 30 Ø В C ₽ \bigcap (1)G G 0 0 (C) x 1 **(B)** x 1 **(D)** x 1 **(E)** x 1 5/16" x 55mm 5mm Ball end Φ 8mm lock washer Φ 22mm flat washer round hex screw Hex wrench


Please do not assemble with power tools

step 3.

1

Now you may tighten all 5 bolts.






Please do not assemble with power tools

step 4.

1



. .


step 5.

A friendly reminder from us:

Please keep the Allen wrench.



After a period of time, there may be a chance the KD furniture may become loose, please use an Allen wrench to tighten the loose bolts.



Level the furniture, use leveling feet if needed.