




# ASSEMBLY INSTRUCTIONS

| Parts List |                                                                                     |                                                                                     |              |                           |
|------------|-------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------|--------------|---------------------------|
| Pieces     | Schema                                                                              |                                                                                     | Description  | QTY                       |
| A          |    |                                                                                     | Screw        | 4                         |
| B          |    |                                                                                     | Flat washer  | 4                         |
| C          |    |                                                                                     | Lock washer  | 4                         |
| D          |    |                                                                                     | Nut          | 4                         |
| E          |    |                                                                                     | Alu plate    | 4                         |
| F          |    |                                                                                     | Nut cap      | 4                         |
| G          |    |                                                                                     | Wrench       | 1                         |
| H          |    |                                                                                     | PE cap       | Factory already assembled |
| I          |    |                                                                                     | Seat         | 1                         |
| J          | 1                                                                                   |    | Base         | 1                         |
|            | 2                                                                                   |  | Alu plate    | 2                         |
|            | 3                                                                                   |  | Spring plate | 2                         |
|            | 4                                                                                   |  | Screw        | 4                         |
|            | 5                                                                                   |  | Flat washer  | 4                         |
|            | 6                                                                                   |  | Lock washer  | 4                         |
|            | 7                                                                                   |  | Nut          | 4                         |
|            | 8                                                                                   |  | TR           | 1                         |
| K          |  |                                                                                     | Seat Cushion | 1                         |



## WARNING!

- ⊙ This chair has a 250 lbs weight capacity.
- ⊙ Hang cushion over chair frame to dry if it gets wet to prevent mold/mildew.

## ATTENTION:

1. Please read these instructions carefully before assembly.
2. Aluminum is soft metal over tighten may strip threads or break the part.
3. DO NOT use power tools.
4. Check parts against the parts list to make sure you have all parts needed for proper assembly.
5. Familiarize yourself with the inventory of parts and the accompanying illustrations to ensure safe and proper assembly.



# ASSEMBLY INSTRUCTIONS

## ATTENTION:

1. Please read these instructions carefully before assembly.
2. Aluminum is soft metal over tighten may strip threads or break the part.
3. DO NOT use power tools.
4. Check parts against the parts list to make sure you have all parts needed for proper assembly.
5. Familiarize yourself with the inventory of parts and the accompanying illustrations to ensure safe and proper assembly.

## Assembly steps:

1. Turn the table top(A) upside down on the soft clean surface. Loosely attach 4 bolts(D) to the table top. Tighten the bolts at this time. Leave enough play for assembly those table plates.
  2. Loosely attach the legs(C) to the table top with flat washers(E), lock washers(F), nuts(G) and nut caps(H). DO NOT tighten the nuts.
  3. Loosely attach each of the center plates(B) to the legs. Note that the recessed end of each plate goes on the leg last at each corner. Secure using flat washers, lock washers, nuts and nut caps.
  4. Tighten all the bolts and nuts completely. DO NOT over-tighten.
  5. Turn the table onto its legs and use the adjuster feet to level the tables.
- Warning : DO NOT use acid or alkaline washing liquid to clean the product.



| Parts list | Parts picture | Description     | Q'ty                      | Parts list | Parts picture | Description     | Q'ty |
|------------|---------------|-----------------|---------------------------|------------|---------------|-----------------|------|
| A          |               | Table top       | 1                         | D          |               | Bolt<br>(M8*40) | 4    |
| B          |               | Center plate    | 4                         | E          |               | Flat washer     | 12   |
| C          |               | Table leg       | 4                         | F          |               | Lock washer     | 12   |
| J          |               | Adjustable Foot | Factory already assembled | G          |               | Nut             | 12   |
| K          |               | Umbrella ring   | 1                         | H          |               | Nut cap         | 12   |
|            |               |                 |                           | I          |               | Wrench          | 1    |


\* DO NOT OVER TIGHTEN

Made in China

\* NO POWER TOOLS

\* NO SOCKET DRIVERS





H : This part have been assembled by factory already.

1. Before removing all protective packing material and position base on floor. Attach the seat(I) onto the base (J)with Alu plate as the picture, then assemble using bolt(A), flat washers(B), lock washers(C), nuts(D) and nut cap(F). Be sure to the arrows face to front.
2. Tighten all the bolts and nuts. Test the swivel rocker gently. If the rocker does not rock properly, double check the assembly procedure.
3. Remove all protective packaging.
4. Put Cushion(K) on the unit(as shown in the picture).

**Warning :** DO NOT use acid or alkaline washing liquid to clean the product.



**\* DO NOT OVER TIGHTEN**

**\* NO SOCKET DRIVERS**



Made in China

**\* NO POWER TOOLS**

