


# ASSEMBLY INSTRUCTION

## Description : DINING TABLE




### IMPORTANT NOTE :

- Place all wooden parts on a clean and smooth surface such as a rug or carpet to avoid the parts from being scratched.
- Check to be sure that you have all parts and hardware.
- Remove all wrapping materials, including staples & packing straps before you start to assemble.
- Do not tighten all screws / bolts until all completely assembled.
- Keep all hardware parts out of reach of children.

| PART LIST |                     |         |
|-----------|---------------------|---------|
| NO        | DESCRIPTION         | QTY/PCS |
| 1         | TABLE TOP           | 1 PC    |
| 2         | LEG FRAME           | 2 PCS   |
| 3         | CENTER SUPPORT RAIL | 2 PCS   |
| 4         | STRETCHER           | 1 PC    |

| HARDWARE LIST |                     |         |
|---------------|---------------------|---------|
| NO            | DESCRIPTION         | QTY/PCS |
| A             | BOLT M8 x 40        | 8 PCS   |
| B             | BOLT M8 x 60        | 8 PCS   |
| C             | FLAT WASHER 5/16"   | 12 PCS  |
| D             | SPRING WASHER 5/16" | 16 PCS  |
| E             | ALLEN KEY M5        | 1 PC    |

### STEP 1



### STEP 2

