

IMPORTANT NOTE

Carefully remove all the parts from the carton and put them individually on a soft cloth to prevent scratches or other damages occuring to the parts.

We have taken great care in the design of this product and request that you carefully and strictly follow our assembly instructions to ensure a completed product as it was designed.



Part List



Tools required for assembly : <u>Phillips</u> screwdriver

Tools recommended for assembly : Level


Assembly Instructions 2/5


IMPORTANT

* Do not tighten up all the screws until each part is properly assembled.

* You should keep Hex Wrench in a safe place as you may need to tighten up the Head Cap Bolts in the future.

* After assembly item must be level to work properly. Use the included adjustable levelers to level.







STEP 1

Put Cam Lock Screws into the pre-drilled holes of Top (A) Side Panels (B),(C) Base (G) and (H) and tighten.

Assembly Instructions 3/5



Assembly Instructions 4/5



Assembly Instructions 5/5

STEP 6

Attach the Door Pull Handle to Doors (J) and (K) using Machine Screws. (see Figure 2)

Insert the Adjustable Pins into both Side Panels at the desired level.

Place Shelves (I) into position. Adjustable Pin To level the unit, adjust the adjustable levelers on the bottom of unit. (see Figure 3) Insert 16X Wood Screws from the back of the unit and tighten. (see Figure 4) J 0-K (Figure 2) (Figure 3) J K Wood Screw (Figure 4)