

COMPONENTS




ITEM	DESCRIPTION	QTY
A	Back	1
В	Seat	1
С	Legs	1
D	Left facing rail	1
E	Right facing rail	1

*Please note: actual product may look different than illustration.* 

### HARDWARE



STEP |




#### 1.1

Fit (B) seat into (A) back, making sure the wooden dowel fits in the center hole.


Attach the center section using (H1) bolts, (H2) spring washers and (H3) flat washers. Tighten using (H5) wrench.

Please note: Before tightening, make sure the bottoms of (A, B) are flush.




#### 1.2

Finish attaching (B) seat to (A) back using (H4) bolts, (H2) spring washers and (H3) flat washers. Tighten using (H5) wrench.



3

STEP 3



LIMITED WARRANTY

We guarantee our upholstered furniture against defects in construction for a period of one (1) year. When a structural defect is brought to our attention, we will repair or replace it at our option at no charge to the customer (inculdes parts and labor, not transportation costs). Fabric wearability for upholstered furniture is not covered by the warranty. Vacuum for regular cleaning.

PLEASE DISPOSE OF PLASTIC BAG(S) AND CARTON(S) RESPONSIBLY.