SPK-600 Post Mounting and Assembly Instuctions





SURFACE MOUNT INSTALLATION



SPK 600 Template



Drawing Not To Scale