



ASSEMBLY INSTRUCTION

Ax1



Bx1



Cx4



Fx4



Flat Washer

Gx4




Spring Washer

Dx4



Hx1

M8




Ex16




Jx1

M6




1




Cx4

3



2



4

