











# ASSEMBLY INSTRUCTION

## TRANSITIONAL BROWN & TAN WEATHERED WOOD FINISH RUSTIC ELEGANT DETAILED LEG STORAGE SOFA TABLE TV STAND


<b>A</b> Top Panel	<b>B</b> Middle Shelf	<b>C</b> Bottom Panel	<b>D</b> Cross Bar
			
1PC	1PC	1PC	2PCS
<b>E</b> Side Frame	<b>F</b> Bolt-Small Ø4X3/4"	<b>G</b> Screw-Big Ø4X1-1/2"	<b>H</b> Bolt 5/32X1/2"
			
2PCS	4PCS	4PCS	5PCS
<b>I</b> Spacer			
			
4PCS			




This page lists all the contents included in the box. Please take the time to identify the hardware as well as the individual components to this product. AS you unpack and prepare for assembly, place the contents on a carpeted or padded area to protect them from damage.

**1**


Attach the Side Frame (E) to the Top panel (A) by using Bolt-Small (F), and attached the Bottom Panel (C) to the Side Frame (E) as below drawing.

**2**


Attach another Side Frame (E) to the Top Panel (A) by using Bolt-Small (F), fixing the Bottom Panel (C) to Side Frame (E) by using Bolt-Big (G), and then attached the Spacer (I) to the bottom of the Side Frame (E).



**3** Attach the Middle Panel (B) to the Side Frame (E).



**4** Attach the Cross Bar (D) to the back of the Side Frame(E) by using Bolt (H) and then fix the Cross Bar (D) with each other by using Bolt (H).



**Cleaning & Care**

Treat surface with care. Surface is resistant to scratches but is not scratch resistant. Clean surfaces with a dry or damp soft cloth. Do not use abrasive cleaners. Hardware may loosen over time. Periodically check that all connections are tight.