







Assembly Instructions

Slat Rocker










Thank you for purchasing a product. This product has been designed for easy assembly and is constructed for durability. Please take the time to read and follow the assembly instructions carefully. If a part or hardware is missing or you have any difficulties in assembling this product, please contact us.

PARTS LIST:

A		Side Assembly	2	B		Cap Rail	1
				C		Back Seat Apron	1
				D		Front Seat Apron	1
E		Back	1	F		Seat	1


HARDWARE LIST:

G		Hexagon Screw Ø6x50mm	8	H		Screw Ø6x35mm	6
I		Hexagon Screw Ø6x70mm	2	J		Dowel	10
K		Wood button	10	L		M6X14mm	6
M		Hexagonal Wrench	1				



TOOLS REQUIRED (NOT INCLUDED) :




Phillips Head Screw Driver




STEP 1



STEP 2



STEP 3



STEP 4