


ASSEMBLY INSTRUCTIONS



Description : SOFA TABLE

BEFORE ASSEMBLY

Thank you for purchasing this quality product. This product has been designed for easy assembly and constructed for durability.

IMPORTANT NOTE:

- Place all wooden parts on a clean and smooth surface such as a rug or carpet to avoid the parts from being scratched.
- Remove all wrapping material, including staples & packing straps before you start to assemble.
- DO NOT tighten all screws and bolts until completely assembled.
- Keep all hardware parts out of reach of children.





ASSEMBLY TOOLS REQUIRED



NOT INCLUDED







PARTS LIST

When unpacking, please carefully not to discard any parts with the packaging. Before continuing, please make sure you have all of the following parts:

NO	Description	Q'ty	Sketch	NO	Description	Q'ty	Sketch
A	Top	1		C	Side Frame	2	
B	Bottom Shelf	1		D	Adjustable Shelf	1	

HARDWARE LIST


When unpacking, please carefully not to discard any parts with the packaging. Before continuing, please make sure you have all of the following hardware:

NO	Description	Q'ty	Sketch	NO	Description	Q'ty	Sketch
1	Bolt (M6x35mm)	8		2	Flat washer (Φ6.5x 13mm)	8	
3	Lock washer (Φ6.5x 11mm)	8		4	Allen Key (4 x 80mm)	1	
5	Shelf support bracket	4		6	Screw (M3.5x15mm)	4	

STEP 1

Attach side frame (C) to the top (A) with bolt (1), washer (2) and (3) as shown below. Tighten with allen key (4).

Attach side frame (C) to the Bottom Shelf (B) with bolt (1), washer (2) and (3) as shown below. Tighten with allen key (4).



STEP 2

Attach brackets (5) to the unit. Attach the Adjustable Shelf (D) with screws (6) as shown below. Tighten with a screwdriver.

