







# ASSEMBLY INSTRUCTION


## CORNER

<b>A</b> CORNER SEAT	<b>B</b> BACK CUSHION	<b>C</b> WAIST PILLOW
		
1pc	2pcs	1pc
<b>D</b> LEGS (Underneath the corner seat)	<b>E</b> FLAT WASHER (Underneath the corner seat)	
		
4pcs	4pcs	




This page lists all the contents included in the box. As you unpack and prepare for assembly, place the contents on a carpeted or padded area to protect them from damage.

- 
- 1** The legs(D) & flat washer(E) are stored at the bottom of corner seat(A), please take out them for assembly.




- 
- 2** Insert the legs(D) & flat washer(E) to the pre-drilled holes, rotate and tighten it.




---

**3** Put the back cushion(B) on corner seat(A).




---


**4** Put the waist pillow(C) on corner seat(A), the assembly is completed.



## I-Shape:



- 
- 5** The corner can be hooked up with the armless chair together as below. The assembly is completed. (Armless chair & ottoman is not in the corner seat carton)



---

## Cleaning & Care

Treat surface with care. Surface is resistant to scratches but is not scratch resistant. Clean surfaces with a dry or damp soft cloth. Do not use abrasive cleaners. Hardware may loosen over time. Periodically check that all connections are tight.