


ASSEMBLY INSTRUCTION

Description: WOODEN COUNTER CHAIR




IMPORTANT NOTE :

- Place all wooden parts on a clean and smooth surface such as a rug or carpet to avoid the parts from being scratched.
- Check to be sure that you have all parts and hardware.
- Remove all wrapping materials, including staples & packing straps before you start to assemble.
- Do not tighten all screws/bolts until all completely assembled.
- Keep all hardware parts out of reach of children.


Each chair

PARTS LIST		
NO.	COMPONENT	QTY.
1	SIDE MEMBER (LEFT)	1 PC
2	SIDE MEMBER (RIGHT)	1 PC
3	FRONT PANEL	1 PC
4	BACK PANEL	1 PC
5	LOWER PANEL (BACK)	1 PC
6	LOWER PANEL (FRONT)	1 PC
7	CHAIR HEAD	1 PC
8	WOODEN SEAT	1 PC


HARDWARE LIST		
NO.	DESCRIPTION	QTY.
A	ALLEN KEY M4 X 110MM 	1 PC
B	JCBC BOLT M6 X 45MM 	6 PCS
C	JCBC BOLT M6 X 35MM 	4 PCS
D	JCBC BOLT M6 X 20MM 	4 PCS
E	SPRING WASHER 1/4" 	10 PCS
F	FLAT WASHER M6 X 13MM 	14 PCS
G	WOOD BUTTON Ø 14.5 X 9MM 	4 PCS

STEP 1


IMPORTANT NOTICE : PLEASE MAKE SURE ALL ARROWS DIRECTION ARE CORRECT.




STEP 2




STEP 3




STEP 4




STEP 5



STEP 6



STEP 7



STEP 8

