



GolfSim DIY Pro Screen Series

ImpactWhite™ 360 Sport Simulation Front Projection Screen Material

User's Guide – A Type

V.1

Product Description: The *GolfSim DIY Pro* is a Do-it-Yourself impact golf screen that uses our *ImpactWhite™ 360* material. Its edges are finished with a 2-inch velvet covered black leather trim with stainless steel rust-proof grommets for easy DIY installation on frames for golf simulation enclosures. The *ImpactWhite™ 360* is ISF Certified for accurate color reproduction in a dark room environment.

ImpactWhite™ 360 Specifications	
Color	White
Thickness	1.2
Material composition	100% Polyester
Weight	360 g /m ²
Gain	1.0
Viewing Angle	180°

Installation Tips and Precautions

We consider our impact screens a wearable item and the life of them will vary according to their use.


1. Make sure to use the correct side. The ImpactWhite™ 360 screen should have a front and back label.
2. Folding lines/wrinkles are normal due to the packaging. Some creasing may occur but may be removed with a steamer and/or light ironing set to no higher than Polyester.
3. Handle with caution, material is subject to static electricity.
4. Avoid installing/hanging the screen where the ball can strike the grommets directly to prevent damaging the edges.
5. Make sure to allow proper distance for swing range to protect children, pets, ceilings, walls, windows, or any other property.
6. Avoid using golf balls with scuffs or markings to maximize the life of your ImpactWhite™ 360 screen. If possible, use new golf balls.
7. Never place the screen over a window or under constant sun exposure. Solar radiation from direct sunlight destroys the synthetic fibers of the screen.

Standard Sizes Available


Model Number		DIY9.8X8-IPW360-F	DIY9.8X9.8-IPW360-F	DIY9.8X13-IPW360-F
Size	Width	9.8 ft (3000 mm)	9.8 ft (3000 mm)	9.8 ft (3000 mm)
	Length	8ft (2450 mm)	9.8 ft (3000 mm)	13.1 ft (4000 mm)

Front and Rear Side

Front Side
(Projection/Impact)



Back Side



Example of DIY10x10-IPW360-F installed in a Golf Simulator enclosure



Maintenance

- Use a dry microfiber cloth to remove dust from the screen surface.
- When cleaning, use a microfiber cloth dampened with warm water to remove any traces.
- Do NOT rub or apply pressure when cleaning the surface.
- Do NOT use any solutions, chemicals, or abrasive cleaners on the screen surface.

To avoid damage to the screen, please avoid touching the screen directly with your fingers, pens/pencils or any other sharp or abrasive objects.

For Technical Support or an Elite Screens contact in your area,

visit www.elitescreens.com