




MANUAL INSTRUCTION

GAZEBO WITH SIDEWALL CURTAINS

G30014GR



part 1: Precautions and preparations	3-6
part 2: Material list (please check before installation)	7-14
part 3	15-25
	
part 4	26-33
	
part 5	34-49
	
part 6	50-55
	
part 7	56

Outdoor Furniture

We are a professional furniture provider with top-notch factories and outstanding designs, Our mission is to provide consumers with new lifestyles. By collecting consumer feedback, we constantly improve our products and create more choices for consumers. If you want to create your space, We are an ideal choice.

Always.



WARNING

1. Three or more people are required for assembly.
2. A ladder and electric drill may be necessary.
3. Do not erect the structure in heavy winds or inclement weather.
4. It is a temporary, portable shelter that shields you from sunlight and rain. The screens also block flying insects.
5. Do not use candles, matches, or any open flames near the tent.
6. To better align the screws for practical situations, do not fully tighten screws initially.
7. Professional installation is highly recommended

WARNING

- In case of windy weather, please do not stand in the gazebo.
- Please do not stand under the gazebo in case of heavy snowfall.
- For safety, please use expansion screws to reinforce the posts to the ground.
- In windy weather, please tighten the fence and netting to avoid tearing in high winds.
- In extreme weather conditions, you can use a rope to pull the four corners of the gazebo to keep it stable.
- Please clear the snow off the roof in time for the heavy snowfall.
- Make sure all screws are tightened before use.
- Repeat to confirm all screws, buckles and straps every 90 days.
- Please keep all screws loose during the assembly process and tighten them after completing the installation.
- Do not use or store next to a pole with an open flame or flammable chemicals.
- Please note that some parts have sharp edges and should be handled with gloves.
- If any parts are missing, broken, damaged or worn, discontinue use of the product until repairs are made or factory replacement parts are installed.
- Installation of the product in a manner that does not conform to the manufacturer's instructions may result in the loss of the warranty policy for this product.
- Consult your local authorities to check if permits are required to erect the shed .

WARNING

WARNING: This product can expose you to Carbon monoxide, which is known to the State of California to cause birth defects or other reproductive harm. For more information go to www.P65Warnings.ca.gov

I TOOLS REQUIRED

EQUIPMENT REQUIRED(Not included in boxes)

**NOTE:Tools / equipment are not shown to actual size and scale.*



LEVEL



RUBBER Mallet



PHILLIPS SCREW



DRILL



ALLEN KEY

EQUIPMENT REQUIRED(Not included in boxes)

**NOTE:Equipment are not shown to actual size and scale.*



SAFETY HAT



GLOVES



SAFETY GOGGLES



STEPLADDER
(6.5Ft Or More)

Matters needing attention



*Three or more people
are required for
assembloe*



*Do not fully tighten
screws prior to complete
assembly*

Part 2: Material list

(please check before installation)

Parts list

☒



☒



☐



☐



P8-P9

Hareware list

☒



☒



☐




☐




P10-P17

PARTS



M6x16mm
1 X 144




M6x47mm
7 X 28



M6x23mm
2 X 64




M6x15mm
8 X 16




M6x25mm
3 X 8



9 X 12



ST4.2x12mm
4 X 24




M5x12mm
10 X 20



M6x10mm
5 X 8



11 X 2



M6x42mm
6 X 4





S4




12 X 1

PARTS


- 


13 X 1
- 

13 X 1
- 

14 X 12
- 

15 X 1
- 

16 X 12
- 


17 X 4
- 

18 X 4


HARDWARE



A X 4




Eb X 4



B X 2




F1 X 4




B1 X 2




F2 X 4



B2 X 2




E1 X 4



B3 X 2



G1 X 2



Ea X 4



G2 X 2

HARDWARE



G3 X 2



G4 X 2



G5 X 2




G6 X 2



G7 X 2



G8 X 2




H X 4




H1 X 4




K X 4



K1 X 4



L X 1




M X 1


HARDWARE




N X 12




Z1 X 24




N1 X 4




U X 104




J X 4




W X 4




T X 4




W1 X 4




T1 X 4



W2 X 4









Z X 56







W3 X 4


HARDWARE

	Y X 92		Q2 X 2
	P X 4		Q3 X 2
	V1 X 2		Q4 X 2
	V2 X 2		Q5 X 2
	V3 X 2		Q6 X 2
	Q1 X 2		S X 2

HARDWARE

	Sa X 2		R6 X 2		S4 X 2
	R1 X 2		R7 X 2		
	R2 X 2		R8 X 2		
	R3 X 2		S1 X 2		
	R4 X 2		S2 X 2		
	R5 X 2		S3 X 2		

Part 3



1






A x 4



J x 4




1 x 12




x4

2




B x 2



P x 2




1 x 8



x2


3




B1 x 2




1 x 8



4




B2 x 2



P x 2




1 x 8



x2


5



B3 X 2







1 X 8



6



U X 104



7






1

x 8



8

x 8






8



1 x 8



8 x 8



9





H x 4



H1 x 4



1 x 16




10



K x 4






K1 x 4




4 x 24





10 x 4



Part 4




11



x4


12




Eb X 4




16 X 12



17 X 4




18 X 4



x4





13



L x 1




15 x 1



14





1 x 8



15



1 x 4




16





E1 X 4



W2 X 4



10 X 8






x4


17




1 x 8







Part 5




18






Attach Z and ZI by lightly tapping with a screwdriver.



19






Attach Z and Z1 by lightly tapping with a screwdriver.



20

Steps 20 and 21 need to be synchronized



21





G2 X 2






1 X 2

Steps 20 and 21 need to be synchronized



22


Steps 22 and 23 need to be synchronized




23




Steps 22 and 23 need to be synchronized





24




M x 1




11 x 2



25



Do not tighten the screw 1 before completing step 26.
It's view from the bottom inside gazebo.




26




F1 X 4



F2 X 4






W X 4




W1 X 4




1 X 24



27 Steps 27,28,29 and 30 need to be synchronized





28



Y x 40




Steps 27,28,29 and 30 need to be synchronized



x2


29




Y X 52

Steps 27,28,29 and 30 need to be synchronized

x2








30





Steps 27,28,29 and 30 need to be synchronized

Notes:


1. When installing the ceiling fix the screws on the central beam first to prevent the iron sheet from falling and causing injury.
2. Do not fully secure the screw until all screws are properly in position.
3. Two persons are needed when installing Part Y. One should secure Part Y's position from inside the gazebo, while the other inserts screws into Part Y from outside the gazebo.



31





32




The marked parts use the same screws as in step 13.


It's view from the bottom inside gazebo.



Part 6




33



T X 4

Steps 33 and 34 need to be synchronized.





34





U X 52

Steps 33 and 34 need to be synchronized.




Pay attention to the sidewall curtain's installation position.







T1 X 4

Steps 35 and 36 need to be synchronized.





36

Steps 35 and 36 need to be synchronized.



Hang the hook attached to the netting on Part A.



Note:

Attach 1 to 2 to secure parts T1 and T (curtains) to gether.
Attach 1 to 3 to secure the back curtain (T).
Attach 1 to 3 to secure the front netting (T1).

37



9 X 12





14 X 12


Installation Completed



To improve wind resistance, **be sure to complete this installation step. If expansion screws or ground nails are not installed, strong winds may topple the gazebo.** Expansion screws are essential for stability on cement surfaces, and ground nails are for grassy surfaces. All are included in the accessories package.




Cement surfaces



Grassy surfaces

HELP CENTER


Question about your product? We're here to help. Visit us at:



Chat Support



Product Inquiry



Orders FAQ



Product Assembly



Returns & Refunds

We Stand Behind the Quality of Their Furniture

If you have any issues with your item, please let us know! We will always do our best to come up with a solution that you will be happy with. Please get in touch with our customer service team before returning the product. And please do not throw the original box(es) if you have not finished assembling or confirmed no quality issues.

Length of return period:

Items can be returned within 30 days of purchase.

In the meanwhile, everything you purchased from us comes with a one-year warranty.

Who is responsible for the return shipping fee:

We will cover the return shipping fees if:

1. Your item has a manufacturing defect in its materials or workmanship. For example, torn wicker or misaligned screw holes. We will send you a prepaid shipping label after photos are sent.
2. Your item has been damaged in transit. For example, glass is broken or wicker is damaged. We will send you a prepaid shipping label after photos are sent.
3. You receive the wrong box(es) due to a warehouse error. We will send you a prepaid shipping label after photos are sent of the wrong SKU numbers on the outer box(es).
4. One or more boxes are lost in transit. We will send you a prepaid shipping label if you no longer want the item.

*However, we still hope to work with you for a better solution instead of a return. Please don't hesitate to contact our customer service team.

Customer will cover the return shipping fees if:

1. You don't like the product(s) after receiving the box(es).
2. You no longer need the product(s) but you have received the box(es).
3. You buy the product(s) by mistake but you have received the box(es).
4. Order/Shipment cancellation failed and you have received the box(es).

Return Request

In order to get a full refund as described in this return policy, all items must be: (1) In a brand new/unused condition, please provide photos before and after packaging.

(2) When returning, all accessories and parts are firmly packed in all original packaging.

If your return does not meet the requirements, you may not get a full refund.

When will I be refunded?

The refund is released once the goods have been returned to our warehouse.

What if the product is damaged/defective outside of the valid return period?

We want you to be a happy customer. Please reach out to us by email and we will come up with a solution to make sure you are satisfied. ☺