ASSEMBLY INSTRUCTIONS

LIST OF WOODEN PARTS			
NO.	DESCRIPTION	Q'TY	
A1	RIGHT SIDE FRAME	1 PC	
A2	LEFT SIDE FRAME	1 PC	
В	BACK SUPPORT	1 PC	
С	SEAT	1 PC	

QUESTION ?

IdentIfy all parts and hardware. If any pleces are missing call our toll free number for replacwment parts. For faster service, have the style number handy when calling.

LIST OF HARDWARE PARTS :

1 1/2" BOLT 6 PCS + 1 E 🛇

WOODEN CAP 6 PCS + 1

NOTE : 1. PLEASE READ THE INSTRUCTION SHEET CAREFULLY BEFORE TOU START ASSEMBLY.

2. PLEASE DO NOT TIGHTEN THE BOLTS UNTIL ALL BOLTS ARE IN THE CORRECT POSITION AS SHOWN IN THE DIAGRAM. 3. PHILLIP'S SCREWDRIVER IS NEEDED IN ASSEMBLING (NOT PROVIDED).



ASSEMBLY INSTRUCTIONS TEAK END TABLE



CUSTOMER SERVICE INFORMATION

Please do not return to the store. If any pieces are missing call our toll free number for replacement parts.

For faster service, have the style number handy when calling.

GENERAL INFORMATION & TIPS

- 1. Please read the assembly instructions prior to assembling the Table.
- 2. To avoid damage, assemble the Table on a non-abrasive surface such as carpet.
- 3. Make sure all nuts and screw tightly fastened before the table is used.
- 4. This table is not for commercial use.

Please make sure you have all parts before beginning assembly. Please wait until all steps are completed before tightening nuts and screw.

- 1. 8" Philips screwdriver
 - For tightening all bolts and screws.
- 2. Wrench
 - For tighten all Nuts. (INCLUDED)



PARTS AND HARDWARE LIST

A. Top Table	B. Tray	C. Leg	D. 1 1/4" Screw
			Contraction of the second seco
Qty: 1 Pc	Qty: 1 Pc	Qty: 4 Pcs	Qty: 4 Pcs + 1
E. Washer	F. Spring Washer	G. Nut	
Qty: 4 Pcs + 1	Qty: 4 Pcs + 1	Qty: 4 Pcs + 1	

