



ASSEMBLY INSTRUCTION

EASTERN KING HEADBOARD

- A** Upper Part of Headboard
- B** Middle Part of Headboard
- C** Lower Part of Headboard
- D** Left Side Panel
- E** Right Side Panel




1pc




1pc



1pc



1pc



1pc

- F** Single-Sided Cover
(In other carton)



1pc

- G** Slate



3pcs

- H** Bolt
1/4" x 50mm



30pcs

- I** Flat Washer
1/4"



30pcs

- J** Lock Washer
1/4"




30pcs

- K** Allen Wrench
1/4"



1pc




This page lists all the contents included in the box. Please take the time to identify the hardware as well as the individual components to this product. As you unpack and prepare for assembly, place the contents on a carpeted or padded area to protect them from damage.

Notice: This product need more than 2 people to assemble it.


1

Attach Upper Part of Headboard (A) & Middle Part of Headboard (B) & Lower Part of Headboard (C) together with Bolt (H), Lock Washer (J) and Flat Washer (I) on holes of Slates (G). Turn the Allen Wrench (K) in Bolt (H).




2

Put Single-Sided Cover (F) on the front of Headboard (A) & (B) & (C). Then stick the velcro at the back of Headboard (A) & (B) & (C).



3

Attach Left Side Panel (D) & Right Side Panel (E) to the Headboard (A) & (B) & (C) with Bolt (H), Lock Washer (J) and Flat Washer (I). Turn the Allen Wrench (K) in Bolt (H).

**Helpful Tip:**

- After assembly, if fabric is not smooth or wrinkled, please iron it.

Cleaning & Care

Treat surface with care. Surface is resistant to scratches but is not scratch resistant. Clean surfaces with a dry or damp soft cloth. Do not use abrasive cleaners. Hardware may loosen over time. Periodically check that all connections are tight.


ASSEMBLY INSTRUCTION

KING BED - FOOTBOARD & SIDE RAILS


- A** Footboard
- B** Side Rails
- C** Wooden Leg
- D** Support Leg
- E** Wooden Slats




1pc




2pcs



2pcs



15pcs



5pcs

- F** Screw
- G** Bolt
1/4" x 75mm
- H** Bolt
1/4" x 50mm
- I** Flat Washer
- J** Lock Washer



20pcs



2pcs



15pcs



17pcs




17pcs

- K** Allen Wrench




1pc



This page lists all the contents included in the box. Please take the time to identify the hardware as well as the individual components to this product. As you unpack and prepare for assembly, place the contents on a carpeted or padded area to protect them from damage.


1

Attached Wooden Leg(C) to the Footboard(A) use Bolt(G), Lock Washer(J) and Flat Washer(I) on both of holes. Turn the Allen Wrench(K) in Bolt(G).




2

Attached Side Rails(B) to the Headboard and Footboard(A).



3

Assembly Support Leg(D) to Wooden Slats(E) use Bolt(H), Lock Washer(J) and Flat Washer(I) by Allen Wrench(K). Assembly Wooden Slats(E) to Side Rail(B) use Screw (F) as showing.



Cleaning & Care

Treat surface with care. Surface is resistant to scratches but is not scratch resistant. Clean surfaces with a dry or damp soft cloth. Do not use abrasive cleaners. Hardware may loosen over time. Periodically check that all connections are tight.