







Outdoor Wicker Glass Top Table





PART LIST

 Wicker Top		 Side Panel	
A	1PC	B	2PCS
 End Panel		 Glass Top	
C	2PCS	D	1PC


HARDWARE LIST

 Short Bolt(M6*40mm)		 Long Bolt(M6*50mm)	
E	4PCS	F	4PCS
 Washer(M6mm)		 Allen Key(M6mm)	
G	8PCS	H	12PCS


EXTRA HARDWARE LIST

 E X1PC	 F X2PCS	 G X3PCS
---	--	--

- Step 1.** Lay wicker Top (A) on a flat surface with underside facing up. Attach Side Panels(B) to Top (A), using Short Bolts(E), Washers(G) and Allen Key (H).
NOTE: Please do not fully tighten bolts until unit is fully assembled.



- Step 2.** Attach End Panels (C) to Side Panels (B), using Long Bolts(F), Washers(G) and Allen Key(H).



Step 3. Turn the table upright and place the glass on the table top.

