





Assembly Instructions

Caution :You must read this before you proceed



Chaise






Parts List

Label	Picture	Description	QTY
A		Chaise Seat	1
B		Chaise Back	1
C		Leg	4
D		Pillow	1


Hardware

Label	Picture	Description	QTY
①		Bolt (M8*60MM)	6
②		Spring Washer	6

③		Flat Washer	6
④		Washer Rings	7
⑤		Allen Key	1

Assembly Preparation

Before Beginning Assembly:



- Read instructions, cover to cover-



- Have 2 adults on hand for assembly-



- Do not assemble on flooring or carpet-




- Assemble on a clean non-marring surface (packing foam)-



- Save all packaging until finished-

Assembly Steps


OVERVIEW



This Chaise has multiple parts and may require up to 30 minutes to assemble. To give you an overview of the Chaise parts, the above picture is to help you put the various Chaise parts into perspective.

Please read through the instructions to familiarise yourself with the parts and steps before assembly.


Step 1



Position the Chaise Seat(A) facedown on a clean, non-marring surface. Unzip the pouches and remove the Chaise Back(B)、Legs(C)、 Pillow(D) and Hardware(①, ②, ③, ④, ⑤) from the inner box


CAUTION: The Chaise and it's parts are large and heavy, always have two or more adults assist you when moving and or lifting these.

Step 2




Install the Chaise Back (B) into the bottom of the Chaise Seat(A) by Bolt (M8*60MM) (①), Spring Washer(②), Flat Washer (③), Washer Rings(④) with the Allen Key (⑤) to fasten all 5 bolts,as shown.

Step 3



Install the Leg (C) onto the Chaise Seat(A) and Chaise Back(B) by placing a Washer Ring(④) onto the stem. Insert the threaded stem into the threaded hole at each corner of the bottom of the Chaise Seat(A) and Chaise Back(B). Tighten the Leg by turning clockwise, as shown. Repeat the same steps to install the remaining 3 legs.


Step 4



Add or remove Spring Washers where needed to achieve stability.


Note: The use of Washer Ring (④) are **OPTIONAL** and is especially useful to help alleviate slight wobbleness. Some Legs may need more than one Washer Ring(④) whilst some Legs may not need any.

Step 5



Close the non-woven fabric by sealing the velcro tape on the underside of the Chaise seat(A).

Step 6























Put the Pillow(D) on the Chaise.

Your Chaise is ready for use.

Note : This Chaise can only be used on a flat, level surface.

Care & Maintenance

-   ● Do not put hot items directly on furniture surface.
 -   ● Do not clean furniture with harsh cleansers or polish.
 -   ● Do not place furniture under direct sunlight.
 -   ● Do not place furniture near heating or cooling vents.
 -   ● Do not write on furniture without a padded barrier to protect the surface.
 -   ● Do not place furniture outside. For indoor use only.
 -   ● Not for commercial use. For residential use only.
 -   ● Stains may be removed with mild soap solution and damp cloth.
 -   ● Children should not climb or jump on the furniture.
-
-   ● Dust and pick-up spills using a clean, non-colored, lint-free cloth.

What is Proposition 65?

Proposition 65 is a California law that requires warning labels on products that may contain one of more than 800-plus chemicals or ingredients that the California Office of Environmental Health Hazard Assessment (OEHHA) has deemed to cause cancer or other reproductive toxicity.

Chemicals and elements on this list include wood dust, brass, and other everyday substances, which can be found in very common household items, such as: lamps, tableware, jewelry, crystal glasses, electric cords, beauty products, automobiles, and furniture.

Why Did I Find a Proposition 65 Warning on My Home Goods Product?

We include Proposition 65 warnings on all of our products because there is always a chance that one of the 800-plus common chemicals and ingredients listed under this law could potentially be on our furniture or packing materials. We risk large fines under this law, if we don't include this warning.

Should I worry?

We realize you may be worried finding this warning on our products, but we want to reassure you that the hazardous exposure limits for any of these chemicals have never been found on furniture products that we've shipped to our customers. Additionally, this warning label is very common and can be found on almost every piece of furniture sold in the state of California.

Just How Common Are Proposition 65 Warnings?

Proposition 65 warnings have become so common in California that it is hard to take a trip to a local bank, grocery store, or restaurant without finding at least one warning. In fact, even the Disney Land Resort has a Proposition 65 warning:

