


OTTOMAN ASSEMBLY

COMPONENTS



ITEM	DESCRIPTION	QTY
A	Ottoman	1
B	Legs	4

Please note: actual product may look different than illustration.

HARDWARE



(H1) x 8
1 1/4" flat washer

LIMITED WARRANTY

We guarantee our upholstered furniture against defects in construction for a period of one (1) year. When a structural defect is brought to our attention, we will repair or replace it at our option at no charge to the customer (includes parts and labor, not transportation costs). Fabric wearability for upholstered furniture is not covered by the warranty. Vacuum for regular cleaning.

PLEASE DISPOSE OF PLASTIC BAG(S) AND CARTON(S) RESPONSIBLY.

OTTOMAN ASSEMBLY

STEP I

1.1

Remove plastic caps from (B) legs, and attach to (A) ottoman using one (H1) washer per leg.

Once legs are secure, turn ottoman upright to check if level.

If ottoman is not level, unscrew the shortest leg and add an additional (H1) washer.

Repeat as needed.

Please note: you may have extra (H1) washers depending on how many you use to level the ottoman.

