

# Sink Overflow

Overflow drain holes prevent the water levels in KOHLER® sinks from overflowing by draining the water before it rises too high.

Without Overflow Drain



With Overflow Drain



THE BOLD LOOK  
OF **KOHLER**®