- 1. Finger Release Latch
- Optional Power Button Mount Area
- Mechanism Seat Plate Mount Area (R & LF)
- 4. Mechanism Trigger Release Activator
- 5. Floor Base for Mechanism
- Front Mechanism Brace Mount for Foot Ottoman Rest Board
- Back Mechanism Bracket Mounts for Back Frame Attachment
- T-Nut Placement to Align Ottoman Board to Mechanism
- 9. Coil & Rocker Cam Area
- 10. Seat Spring & Hartco Spring Clips
- 11. Back Spring & Harco Spring Clips
- 12. Seat Insulated Tie Wire & Hog Ring (Stationizes Spring Unity) (2)
- Back Insulated Tie Wire & Hog Ring (Stationizes Spring Unity) (1)
- 14. Heavy-Duty Hardwood Seat Box Assembly

- 15. Front Arm Post
- 16. Back Arm Post
- Inside Back Frame Post (Attaches to #7 Mechanism Brackets)
- 18. Back Wing Plate
- 19. Top Back Rail
- 20. Cardboard Insulator (Wraps Over Inside Top & Side Arm Frame)
- 21. Front Ottoman Foot Rest Board
- 22. Thick Poly-Foam Ottoman Padding
- 23. Upholstery Cover Over Ottoman
- 24. Seat Foam Core
- 25. Poly-Dacron Wraps Over Seat Cushion Core
- 26. Seat Cover
- 27. Front Arm Upholstery Cover
- 28. Top Arm Upholstered Pillow Pad
- 29. Seat Spring "Shoddy Pad" (Insulation Between Seat Foam & Spring)
- 30. Lower Back Fiber Padding
- 31. Back Upholstery Cover
- 32. Back Filling with Poly-Dacron Fiber
- 33. Inner Back Upholstery Cover Between Spring & Upholstery

