




# Assembly Instruction










## Hardwares


NO	Description	Sketch	Q' TY
A	Allen key		2pcs
B	Touch up pen		1pc










# Assembly Instruction

## Hardwares

NO	Description	Sketch	Q' TY
A	Allen key		2pcs
B	38mm Bolt		8pcs
C	28mm Bolt		4pcs
D	Screw Cap		4pcs
E	Flat washer		12pcs
F	Spring washer		8pcs
G	shelf pin		16pcs
H	wood screws		16pcs
	Touch up pen		1pc







G



# Assembly Instruction

## Hardwares

NO	Description	Sketch	Q' TY
A	hooking		4pcs
B	wood screws 1/2"		16pcs
C	wood screws 1"		4pcs



To expand shelf, remove screws, expand shelf extensions, then secure shelf extensions by reinstalling screws.