


ASSEMBLY INSTRUCTIONS & PARTS IDENTIFICATION


SLIDING 2 DOORS 70" CONSOLE
DARK CHARCOAL FINISH

Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts that may have come loose inside the carton during shipment.

Parts key					
No	Qty	Description	No	Qty	Description
1	1 pc	Storage Box	5	3 psc	Shelf
2	2 pcs	Sliding Door	6	4 pcs	Floor Glide
3	2 sets	Pull w/Screws	7	1 pc	Floor Leveler
4	4 sets	Sliding Wheel & Lock w/Screws - 2 pcs			



TO REACTIVATE DOOR
PIN, PRESS THE BUTTON
WHEN IN THE BOTTOM
POSITION



TO RELEASE DOOR PIN,
MOVE THE BUTTON TO
THE BOTTOM POSITION

