


**This page is for printing and document  
formatting specifications only.  
THIS PAGE DOES NOT PRINT**



**DO NOT** scale the artwork for printing. Each page has been scaled for proper scaling of parts.

**Page 1** will be the cover page and first page printed after this specification page. Any blank pages needed will be placed at the end of the booklet.

**Printer** to arrange booklet pages in proper sequence according to page number.



Foundations Worldwide, Inc.  
5216 Portside Dr., Medina, OH 44256 USA • PH: 1 330.722.5033 • FAX: 1 330.722.5037  
www.childcraftbaby.com

# Universal Select™ Dresser

## Model Covered: F09409

**KEEP INSTRUCTIONS FOR FUTURE USE.**

**FOR CUSTOMER SERVICE CALL  
1-877-716-2757  
(outside of U.S. 330-722-5033). DO NOT CALL  
RETAILER OR RESELLER FOR SERVICE  
AS THEY ARE NOT AUTHORIZED TO  
RESOLVE ANY SERVICE ISSUES.**

**FOR WARRANTY AND FEDERAL SAFETY STANDARD  
COMPLIANCE CERTIFICATES, PLEASE VISIT OUR  
WEBSITE AT  
wwwFOUNDATIONS.COM**

### **ASSEMBLY ASSISTANCE**

**IMPORTANT: Retain for future reference and read carefully.**

Foundations strives for the highest quality in our products but occasionally a missing part or problem can occur during assembly.

If any parts are missing or broken or you need assistance with assembly, DO NOT return the product to your dealer. Go to our website at [www.foundations.com](http://www.foundations.com) or call Foundations for assistance at 1-877-716-2757 (U.S. Only) or 1-330-722-5033 (Monday through Friday, 9:00 a.m.– 4:00 p.m. Eastern Time). Please have the model number and manufacture date available when you call or write us at:  
Foundations, 5216 Portside Dr., Medina, OH. 44256

### **ASSEMBLY INSTRUCTIONS**

- Adult assembly required.
- Read all instructions BEFORE assembly and USE of product.
- Unpack carton, remove packing materials, including polybag. Identify and check all parts.



Record the information for your product here:

Model number: \_\_\_\_\_

Manufacture date: \_\_\_\_\_

PO number: \_\_\_\_\_

## PARTS LIST


Part Description	Part Number	Quantity
A. End Panel - Left	23100602	1
B. End Panel - Right	23100603	1
C. Bottom Front Rail	23100604	1
D. Front Rail	23100605	1
E. Upper Front Rail	23100606	1
F. Top Front Rail	23100607	1
G. Top Panel	23100608	1
H. Base	23100609	1
I. Upper Back	23100610	1
J. Lower Back	23100611	1
K. Top Drawer Front	23100612	1
L. Lower Drawer Front	23100613	2
M. Top Drawer Back	23100614	1
N. Lower Drawer Back	23100615	2
O. Top Drawer Left Side	23100616	1
P. Top Drawer Right Side	23100617	1
Q. Lower Drawer Left Side	23100618	2
R. Lower Drawer Right Side	23100619	2
S. Support Rail	23100620	3
T. Drawer Bottom	23100621	3
U1. Bolt 35mm	11200710	6
U2. Bolt 25mm	11200763	4
V. Knob Screw	11200711	6
W. Flat Head Screw	11200712	24
X. Flat Head Screw	11200713	9
Y. Push-In Rivet	11200714	20
Z. Flat Washer	11200715	10
AA. Locking Washer	11200716	10
BB. Knob	11200717	6
CC. Screw Bracket - Front	11200718	3
DD. Screw Bracket - Rear	11200719	3
EE. Allen Wrench	11200720	1

## PREPARATION


Carefully remove and lay out all hardware and parts. Check quantities and match the parts list. Construct hutch on an even flat floor. Note: during the assembly process whenever using screws or bolts, check each with the parts list by letter and size identification. Place each screw or bolt on the diagram of the item which is sketched actual size. Be sure to use the proper size specified in the assembly directions. If any parts are missing or broken or you need assistance with assembly **DO NOT return your product to the dealer.** Please identify the furniture by the model number identification stamped on the assembly when you call or write to Foundations. Make note of all identification numbers and include this information with your request. **DO NOT Substitute Parts!**

## SUGGESTED TOOLS

#2 Medium Straight Screwdriver




Furniture Parts




Hardware Package

## STEP 1




AB20190\_G4

## STEP 2




AB20190\_G5

**STEP 3**




AB20190\_G6

**STEP 5**




AB20190\_G8

**STEP 4**




AB20190\_G7

**STEP 6**




AB20189\_G9

**STEP 7**




AB20189\_G1

**STEP 9**




AB20189\_G12

**STEP 8**




AB20189\_G15

**STEP 10**



AB20189\_G13

## STEP 11



AB20190\_G14

## **WARNING**

**Serious or fatal crushing injuries can occur from furniture tipover. To help prevent tipover:**

- Install tipover restraint provided.
- Place heaviest items in the lower drawers.
- Unless specifically designed to accommodate, do not set TVs or other heavy objects on the top of this product.
- Never allow children to climb or hang on drawers, doors, or shelves.
- Never open more than one drawer at a time.

**Use of tipover restraints may only reduce, but not eliminate, the risk of tipover.**

## **Maintenance Cleaning and Storage**

### **MAINTENANCE:**

Upon completion of the assembly, check to make sure all screws, bolts and connectors are tightened and secure.

Periodically check furniture for damaged hardware, loose joints, missing parts or sharp edges before and after assembly and frequently during use.

**DO NOT** use furniture if any parts are missing or broken.

If any parts are missing, broken or you need assistance **DO NOT** return furniture to your dealer.

Call Foundations at 330.722.5033 and include model identification numbers recorded on page 1.

**DO NOT** substitute parts.

### **CLEANING:**

Mix a mild solution of gentle dishwashing soap and water, apply to surface using a clean cloth lightly dampened in the solution. Rinse well with clear water using a soft clean cloth, then dry all surfaces with a soft dry cloth.

**DO NOT** use abrasive cleaners or any cleaners with harsh chemicals that would contact a child's skin, scouring pads, steel wool or coarse rags. This furniture should be treated the same as any fine furniture.

### **STORAGE:**

**When storing furniture use caution as extreme temperature or humidity changes could be harmful. Use caution when a vaporizer is in use. Always aim vapor stream away from furniture as well as away from any wood furniture item.**

**After completing the assembly the user is advised to read and be aware of ALL WARNINGS, CAUTIONS, CLEANING, STORAGE USE AND MAINTENANCE. Please store the complete set of assembly directions for future referral.**

## Universal Select™ La Commode

### Couvert Modèle: F09409

CONSERVER LES INSTRUCTIONS POUR USAGE FUTUR.

POUR LE SERVICE À LA CLIENTÈLE, APPELEZ LE 1-877-716-2757

(à l'extérieur des É-U, appelez le 1-330-722-5033).  
N'APPELEZ PAS LE VENDEUR OU LE DISTRIBUTEUR  
POUR LE SERVICE À LA CLIENTÈLE, CAR ILS NE SONT  
PAS AUTORISÉS À RÉSOUDRE CE  
GENRE DE PROBLÈMES.

GARANTIE ET FÉDÉRAL DE SÉCURITÉ STANDARD  
CERTIFICAT DE CONFORMITÉ Le, S'IL VOUS PLAÎT  
VISITEZ NOTRE SITE INTERNET  
www.foundations.com

### GUIDE D'ASSEMBLAGE


**IMPORTANT: le conserver pour référence ultérieure.  
Lisez attentivement.**

Foundations s'efforce de la plus haute qualité dans  
notre  
produits, mais de temps en temps une partie ou prob-  
lème manquant peuvent se produire lors de  
l'assemblage.

Si des pièces sont manquantes ou brisées ou vous avez  
besoin aide au montage, ne renvoyez pas les  
produit à votre revendeur. Allez sur notre site Web à  
www.childcraftbaby.com ou appel Foundations  
pour l'aide au 1-877-716-2757 (États-Unis uniquement)  
ou 1-330-722-5033 (du lundi au vendredi, 09:00-16:00  
heure de l'Est). S'il vous plaît avoir le numéro de modèle  
et la date de fabrication lorsque vous appelez ou  
écrivez-nous à: Foundations Worldwide, Inc.  
5216 Portside Dr Medina, OH 44256

### INSTRUCTIONS D'ASSEMBLAGE

- L'assemblage doit être effectué par un adulte.
- Veuillez lire toutes les instructions AVANT de commencer l'assemblage et l'utilisation du produit.
- Déballez le produit et enlevez les matériaux d'emballage, y compris le sac en polyéthylène. Identifiez et vérifiez toutes les pièces.



Inscrivez les renseignements de votre produit ici :

Numéro de modèle : \_\_\_\_\_

Date de fabrication : \_\_\_\_\_

No de commande : \_\_\_\_\_

### LISTE DES PIÈCES


Description des pièces	Numéro de pièce	Quantité
A. Panneau de fin - Gauche	23100602	1
B. Panneau Fin - Droit	23100603	1
C. Bas Rail avant	23100604	1
D. Rail avant	23100605	1
E. Haut Rail avant	23100606	1
F. Haut Rail avant	23100607	1
G. Panneau du haut	23100608	1
H. Base de	23100609	1
I. Haut Retour	23100610	1
J. Basse Retour	23100611	1
K. Le tiroir supérieur avant	23100612	1
L. Basse tiroir avant	23100613	2
M. Le tiroir supérieur retour	23100614	1
N. Basse tiroir retour	23100615	2
O. Le tiroir supérieur Côté gauche	23100616	1
P. Le tiroir supérieur Côté droit	23100617	1
Q. Basse Drawer Côté gauche	23100618	2
R. Basse Drawer Côté droit	23100619	2
S. Rail de support	23100620	3
T. Tiroir du bas	23100621	3
U1. Boulon 35mm	11200710	6
U2. Boulon 25mm	11200763	4
V. Bouton Vis	11200711	6
W. Vis à tête plate	11200712	24
X. Vis à tête plate	11200713	9
Y. Poussez-In Rivet	11200714	20
Z. Rondelle	11200715	10
AA. Verrouillage Laveuse	11200716	10
BB. Bouton	11200717	6
CC. Vis Support Avant	11200718	3
DD. Support à vis - Arrière	11200719	3
EE. Clé Allen	11200720	1

### PRÉPARATION


Retirez délicatement et exposer tout le matériel et les pièces.  
Vérifier les quantités et correspondre à la liste des pièces.  
Construire huche à un étage même plat.  
Note: pendant le processus d'assemblage chaque fois utilisant  
des vis ou des boulons, vérifier chacun avec la liste des pièces  
par lettre et l'identification de la taille. Placez chaque vis ou  
boulon sur le schéma de l'élément qui est esquissé taille  
réelle. Veillez à utiliser la bonne taille spécifiée dans les  
directions d'assemblage. Si des pièces sont manquantes ou  
brisées ou si vous avez besoin d'aide avec l'ensemble NE  
PAS retourner votre produit au distributeur. S'il vous plaît  
identifier la cage par le numéro de modèle identification gravé  
sur l'ensemble lorsque vous appelez ou écrivez des  
Foundations. Prenez note de tous numéros d'identification et  
comprennent cette information avec votre demande.  
**Ne pas remplacer les pièces!**

### OUTILS SUGGÉRÉS

# 2 Moyen tournevis droit




Parties de Meubles




Crèche Parties

### ÉTAPE 1




AB20190\_G4

### ÉTAPE 3




AB20190\_G6

### ÉTAPE 2




AB20190\_G5

### ÉTAPE 4




AB20190\_G7

ÉTAPE 5




AB20190\_G8

ÉTAPE 7



AB20189\_G10


ÉTAPE 6



AB20189\_G9

14


ÉTAPE 8



AB20189\_G15


15

ÉTAPE 9




AB20189\_G12

ÉTAPE 11



AB20190\_G14

ÉTAPE 10



AB20189\_G13

# **AVERTISSEMENT**

**Des blessures graves ou mortelles peuvent se produire lorsqu'un meuble se renverse.**

**Pour éviter les renversements :**

- Installer retenue de renversement fourni.
- Placez les articles les plus lourds dans les tiroirs du bas.
- Sauf spécifiquement conçu pour accueillir, ne réglez pas les téléviseurs ou d'autres objets lourds sur le dessus de ce produit.
- Jamais permettre aux enfants de grimper ou de se pendre drawers, portes ou des étagères.
- Ne jamais ouvrir plus d'un tiroir à la fois.

**Les dispositifs anti-renversement peuvent uniquement réduire et non pas éliminer les risques de renversement.**

## **Entretien Nettoyage et Stockage**

### **ENTRETIEN:**

À la fin de l'assemblage, assurez-vous que toutes les vis, boulons et connecteurs sont serrés et sécurisés. Vérifiez périodiquement meubles pour le matériel endommagé, les joints lâches, des pièces manquantes ou des bords tranchants avant et après l'assemblage et fréquemment pendant l'utilisation.

**NE PAS** utiliser meubles si des pièces sont manquantes ou brisées.

Si des pièces sont manquantes, cassées ou vous avez besoin d'aide **NE PAS** retourner meubles à votre revendeur.

Appelez au 330.722.5033 Foundations et inclure les numéros d'identification de modèles enregistrés à la page 10.

**NE PAS** remplacer les pièces.

### **NETTOYAGE:**

Mélanger une solution douce de savon à vaisselle doux et de l'eau, appliquer sur la surface à l'aide d'un chiffon propre légèrement humecté dans la solution. Rincez à l'eau claire à l'aide d'un chiffon doux et propre, puis séchez toutes les surfaces avec un chiffon doux et sec.

**NE PAS** utiliser de nettoyeurs abrasifs ou de produits de nettoyage avec des produits chimiques qui contacter la peau d'un enfant, de tampons à recurer, de laine d'acier ou de chiffons grossiers. Cette meubles devrait être traité de la même façon que tout beaux meubles.

### **ESPACE DE RANGEMENT:**

Lors du stockage meubles à utiliser avec précaution les changements de température ou d'humidité extrêmes que pourraient être nocives.

Soyez prudent lorsque vous d'un vaporisateur est en cours d'utilisation. Toujours viser flux de vapeur loin de meubles ainsi que l'écart de tout élément de mobilier en bois.

Après avoir terminé l'assemblage l'utilisateur est invité à lire et être conscient de

Tous les avertissements, mises en garde, le nettoyage, utilisez de stockage et de maintenance. S'il vous plaît stocker l'ensemble des directions de montage pour référence future.

