

COLLAR TILT UMBRELLA OPERATION INSTRUCTIONS

Thank you for purchasing !! Your umbrella should give you years of enjoyment.

YOUR BOX SHOULD CONTAIN:

1. Umbrella frame with cover
2. Bottom pole
3. Finial top cap

TWIST TO TILT



TO OPEN UMBRELLA AND TILT:

STEP 1: To open: Umbrella must be set up in a straight position. Once in a standing position start cranking the handle until it stops. Umbrella should be completely open.

STEP 2: To tilt: Once the umbrella is completely open, twist top housing on the crank Clockwise until umbrella tilts. **Please note the umbrella should tilt one position.****

TO CLOSE UMBRELLA:

STEP 1: Turn top of crank counter Clockwise until the umbrella is back in a straight position.

STEP 2: Once the umbrella is in a straight position, start cranking in the opposite direction. (If the hub stops half way, please make sure umbrella is in a straight position) May require assistance if umbrella doesn't close all the way.

WARRANTY: We honor one year warranty from the time of purchase, only due to any manufactures defects from normal use. We will not honor the warranty, if defect is caused by improper use; improper maintenance, or if item is damaged due to weather conditions. If you have any warranty questions, please contact your retailer.