




9




10




11



12



Recommended Maximum Weight



*Unit in Pound(lbs)

WARNING:

>This unit has been designed to support the maximum loads shown. Exceeding these load limits could cause sagging, instability, product collapse, and/or serious injury.

>DO NOT allow children to climb on unit.

>Put heavier items on lower shelves.

Assembly Instruction

Large Entertainment Center


DIMENSION : 47.2" (W) x 19.5"(H) x 15.9" (D)

00:30


Approx. 30 minutes


















Recomm. 2 Person




Tool Required



No	Hardware List	Qty
1	SHORT ROUND POLE 	6pcs
2	SMALL ROUND LEG 	6pcs
3	PVC LEG WITH PLUG 	7pcs
4	MINI FIX + HOUSING 4A  4B 	8sets
5	C/B SCREW 	8pcs
6	DOWEL 	16pcs
7	MAGNET SET 7A  7B 	2sets
8	DOOR SPRING 	4pcs
9	HANDLE 	2pcs
10	P/H TAPPING SCREW 	4pcs
11	SHELF SUPPORT 	4pcs
12	POWER PIN 	20pcs
13	INSERT CAP 	6pcs

No	Parts List	Qty
A	TOP PANEL	1pcs
B	CENTER PANEL	1pcs
C	BOTTOM PANEL	1pcs
D	LEFT SIDE PANEL	1pcs
E	CENTER LEFT SIDE PANEL	1pcs
F	CENTER RIGHT SIDE PANEL	1pcs
G	RIGHT SIDE PANEL	1pcs
H	SHELF PANEL	1pcs
I	LEFT DOOR PANEL	1pcs
J	RIGHT DOOR PANEL	1pcs
K	BACK PANEL	2pcs



USEFUL HINTS BEFORE YOU START:

1. Read each step carefully before starting.
2. It is important that each step is performed in correct order to avoid difficulties.
3. Identify, sort and count the parts before assembly.
4. Assemble your furniture on packaging cardboard to prevent scratch or damage.
5. Clean the product with mild cleanser using soft damped cloth. Do not use harsh or abrasive cleanser.
6. Using incompatible hardware might cause damage to product.

