


## PARTS AND FEATURES


It is important to know your vacuum cleaner's parts and features to ensure its proper and safe use. Review these before using your vacuum cleaner.



## REPLACEMENT PARTS

Part	Part No.
Belt	20-53013
Dust Bag (2-pack)	20-53291
Dust Bag (6-pack)	20-53292
Exhaust Filter	20-86880
Motor Safety Filter	20-81002
PowerMate® Agitator Assembly	591015101
To order a replacement part call 1-877-531-7321	

## CANISTER



## ATTACHMENTS


### CREVICE TOOL




### DUSTING BRUSH




### ATTACHMENT HOLDER



## HANDLE & HOSE ASSEMBLY



## TELESCOPING WAND



## POWERMATE®

