### **DINING TABLE**

## **ASSEMBLY INSTRUCTIONS**



#### **ASSEMBLY TIPS:**


- 1. Remove hardware from box and sort by size
- 2. Please check to see that all hardware and parts are present prior start of assembly.
- 3. Please follow attached instruction in the same sequence as numbered to assure fast & easy assembly.



#### Warning!

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishment

# **PARTS IDENTIFICATION**



## **HARDWARE IDENTIFICATION**

1	WRENCH	1PC
2	HEX BOLT	8PCS
3	LOCK WASHER	8PCS
4	FLAT WASHER	8PCS

#### STEP 1

Place table top upside down on soft surface, then align and fasten all legs to table top using bolt, lock washer and flat washer and tighen with wrench.

