
24" Barstool



>>assembly instructions

Congratulations on your latest purchase.

Now what? Don't start sweating over this box of parts. This will be easy. We did the hard work for you. All you need to do is follow our simple instructions and you'll be on your way to transforming your room in no time. Good luck --though we're confident you won't need it.

before you begin

- 1. Check for damaged or missing parts.
- 2. Use the carton as a working surface to prevent product damage during assembly.
- 3. Gather all tools prior to assembly.

table of contents


introduction	2
hardware	4
parts list	5
assembly	6 - 12

hardware


(A) x 4 5/16" x 90mm round hex screw		(B) x 2 5/16" x 70mm round hex screw		(C) x 4 5/16" x 60mm round hex screw
(D) x 2 1/4" x 45mm round hex screw	(E) x 2 1/4" x 20mm round hex screw	(F) x 10 Φ 8mm lock washer	(G) x 10 Φ 22mm fla	(H) x 4 t washer Φ 6mm lock washer
(I) x 4 Φ 15mm flat washer	(J) x 2 plug	(K) x 1 dowel 10x40mm	(L) x 1 5mm Ball er Hex wrench	

ITEM DESCRIPTION QUANTITY


1	chair back	1
2	seat cushion	1
3	front leg	1
4	bar	2



step 1.




step 2.







MMMMM





step 3.







step 4.


1

Now you may tighten all 6 bolts.







step 5.



step 6.






step 7.

A friendly reminder from us:

Please keep the Allen wrench.



After a period of time, there may be a chance the KD furniture may become loose, please use an Allen wrench to tighten the loose bolts.



Level the furniture, use leveling feet if needed.