
Assembly Instruction

REVERSIBLE SECTIONAL


Thank you for your purchase of this Reversible Sectional. Your new sectional can be assembled with either a leftside facing chaise (configuration #1) or a right side facing chaise (configuration #2). See instructions below.

Configuration#1




see page 2~3 for assembly instruction

Configuration#2




see page 4~5 for assembly instruction





COMPONENT LIST

NO.	DRAWING	QTY	DESCRIPTION
Α		1	BACK FRAME
В		1	SEAT FRAME
С		1	ARM FRAME
D		3	BACK CUSHION
Е		3	SEAT CUSHION
F		1	PILLOW
G	\Diamond	4	LEG
Н		2	BOLT
I	© ()::::::::::::::::::::::::::::::::::::	4	BOLT
J		6	LOCK WASHER
K	0	6	FLAT WASHER
L		1	ALLEN KEY


Please follow the drawings below to assemble the item. Legs are stored in the box and put in the bottom of sofa. Please take out for assembly.









G








COMPONENT LIST


NO.	DRAWING	QTY	DESCRIPTION
Α		1	BACK FRAME
В		1	ARM FRAME
С		1	SEAT FRAME
D		1	LSF BACK CUSHION
Е		1	RSF BACK CUSHION
F		1	CORNER BACK CUSHION
G		1	LARGE SEAT CUSHION
Н		1	MIDDLE SEAT CUSHION
I		1	CORNER SEAT CUSHION
J		1	PILLOW
K		4	LEG
L	(9) (1) (1) (1) (1) (1) (1) (1) (1) (1) (1	2	BOLT
M	(i) (i) (ii) (ii) (ii) (ii) (ii) (ii) (4	BOLT
N	<u></u>	6	LOCK WASHER
0		6	FLAT WASHER
Р		1	ALLEN KEY


Please follow the drawings below to assemble the item.


Legs are stored in the box and put in the bottom of chaise. Please take out for assembly.



Step 4










3

Configuration#2






NO.	DRAWING	QTY	DESCRIPTION
Α		1	BACK FRAME
В		1	SEAT FRAME
С		1	ARM FRAME
D		3	BACK CUSHION
Е		3	SEAT CUSHION
F		1	PILLOW
G	igoplus	4	LEG
Н		2	BOLT
- 1		4	BOLT
J	Ø	6	LOCK WASHER
K	0	6	FLAT WASHER
L		1	ALLEN KEY


Please follow the drawings below to assemble the item.

Legs are stored in the box and put in the bottom of sofa. Please take out for assembly.


Step 1




Step 2




Step 3




Step 4




Step 5



Step 6






COMPONENT LIST


NO.	DRAWING	QTY	DESCRIPTION
Α		1	BACK FRAME
В		1	ARM FRAME
С		1	SEAT FRAME
D		1	LSF BACK CUSHION
Е		1	RSF BACK CUSHION
F		1	CORNER BACK CUSHION
G		1	LARGE SEAT CUSHION
Н		1	MIDDLE SEAT CUSHION
I		1	CORNER SEAT CUSHION
J		1	PILLOW
K	*	4	LEG
L	() () () () () () () () () () () () () (2	BOLT
M	② () () () () () () () () () () () () ()	4	BOLT
N	٥	6	LOCK WASHER
0		6	FLAT WASHER
Р		1	ALLEN KEY

Please follow the drawings below to assemble the item.


Legs are stored in the box and put in the bottom of chaise. Please take out for assembly.




Step 4




Step 2




Step 5



Step 3



Step 6



CARE INSTRUCTION FOR 100% POLYESTER FURNITURE:

In order to maintain the original appearance of your 100% polyester furniture, please follow below care procedures:

- Avoid exposing furniture directly to sunlight or heating and air conditioning outlets. Sunlight and / or exposure to heating and air conditioning outlets will fade/damage 100% polyester. Do not place your upholstered furniture too close to windows, radiators, or vents, and be sure to use window treatments to block the sun's rays.
- Wipe with a soft brush to remove dust.
- Wipe 100% polyester with professional cleanser.



For items use on wooden floor, hard surfaces or carpets, it is recommended to Install protective pads under all legs and supports to avoid/prevent from damages/scratches and discoloration.