



CORNER SOFA(S) 34"W X 34" D X 29"H



ARMLESS SOFA(S) 28"W X 34" D X 29"H



CLUB CHAIR(S) 40"W X 34" D X 29"H



OTTOMAN(S) 28"W X 28" D X 18"H



RECTANGLE COFFEE TABLE 48"W X 24" D X 18"H



END TABLE(S) 24"W X 24" D X 18"H



CUP TABLE(S) 15"W X 34"D X 25"H

## **CUSHIONS AND CUSHION COVERS:**



**Back Cushions** 



Seat/Ottoman Cushions



Corner Short Side Cushions

## Depending on product availability, the product will come in one of two ways:

You will receive cushion covers in the color you selected.



You will receive cushion covers in the color you selected and the base set pictured above.

## **Color Options:**



To prevent tearing of your cushion covers, please remove existing cushion covers before putting on the color you selected.

## ADDITIONAL REPLACEMENT PARTS AVAILABLE:



Foot



Leveler



**Cushion Casing** 

\*\*Not all items shown in this guide may come with the selected purchase. This guide shows all products and replacements made for this specific collection.