

## Maestro cleaning and maintenance manual


For cleaning, use only water and neutral soap.

Do not use abrasive sponges, corrosive sponge, corrosive & alcoholic cleaners.

Do not use electrical screw drivers for the assembly and do not over strength during the plug fixation.

In case of scratch, sometime is possible to diminish the damage by restoring with soft towel wetted with some oil drop or any cream.

We recommend using only the plastic gasket:



Place silicone ring between the plug and the basin:

