

Assembly Instructions



48"x24"x36HT BUFFET WITH TURNED LEGS



• Thank you for purchasing this product. This product has been designed for easy assembly and constructed for durability. Please take the time to read and follow the assembly instructions carefully. If a part or hardware is missing or have any difficulties in assembling this product, Please contact us


PARTS LIST :

1	TABLE TOP	1 PC.
2	TABLE LEG	4 PCS.



HARDWARE LIST :


A	FLAT WASHER(5/16")	8 PCS.
B	LOCK WASHER(5/16")	8 PCS.
C	HEXAGON NUT(5/16")	8 PCS.
D	WRENCH(12.8MM)	1 PC.



IMPORTANT NOTE :

- Place all wooden parts on a clean and smooth surface such as a rug or carpet to avoid the parts from being scratched. Check to be sure that you have all parts and hardware. Remove all wrapping materials, including staples & packing straps before you start to assemble.
- Keep all hardware parts out of reach of children.
- **DO NOT TIGHTEN BOLTS/SCREWS UNTIL ALL COMPLETELY ASSEMBLED.**

*** PLEASE REMOVE PLASTIC PROTECTING CAP BEFORE ASSEMBLE LEG TO TOP.**



*** STAND THE TABLE TO UPRIGHT POSITION.**

CARE AND MAINTENANCE

The touch of a soft cloth is all the maintenance your wood pieces will ever need. Never use harsh chemicals or abrasive cleaners, as they could mark or destroy finish.

MADE IN MALAYSIA