HOLTKÖTTER INTERNATIONAL, INC.

155 Hardman Avenue South, South St. Paul, MN 55075

fax: (888) 552-8661 • phone: (800) 899-5444

www.holtkoetter.com e-mail: customerservice@holtkoetter.com

CAUTION, IMPORTANT SAFETY INSTRUCTIONS

This portable luminaire has a polarized plug (one blade is wider than the other) as a feature to reduce the risk of electrical shock. This plug will fit a polarized outlet only one way. If the plug does not fit fully into the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Never use with an extension cord unless plug can be fully inserted. Do not alter the plug.

INSTRUCTIONS PERTAINING TO A RISK OF FIRE, ELECTRIC SHOCK, EXPOSURE TO EXCESSIVE UV RADIATION OR INJURY TO PERSONS

WARNING - To reduce the risk of FIRE, ELECTRIC SHOCK, EXPOSURE TO EXCESSIVE UV RADIATION OR INJURY TO PERSONS:

- 1. Turn off power/unplug and allow to cool before replacing bulb.
- 2. Bulb gets HOT quickly. Contact only switch/plug when turning on.
- 3. Do not touch hot lens, guard or enclosure.
- 4. Do not remain in light if skin feels warm.
- 5. Do not look directly at lighted lamp.
- 6. Keep lamp away from materials that burn.
- 7. Use only with a 100 Watt, bayonet base halogen bulb or smaller bulb.
- 8. Do not touch the bulb at any time. Use a soft cloth. Oil from skin may damage bulb.
- Do not operate the portable luminaire with a missing or damaged guard, lamp containment barrier or UV filter.

ASSEMBLY INSTRUCTIONS FOR

Halogen Floor Lamp 6451/2

Please make sure that the following parts for your lamp are enclosed:

- 1. Reflector (2 each)
- Aluminum Rings (attached to lamp)
- 3. Glass Shield (2 each)
- 4. Allen Wrench (packed inside bulb box)
- 5. Large Washer (4 each already installed)
- 6. Handle with plastic protector (2 each)
- 7. Small Plastic Washer, 2 each (1 attached to each reflector)
- 8. Small Plastic Nut, 2 each (1 attached to each reflector)
- 9. Bayonet Base Halogen Bulb (2 each)
- 10. Floor Lamp

Care Instructions

Use only a soft, dry cloth to clean. If necessary, a slightly damp, soft cloth may be used to spot clean. Do not use common household cleaners or brass cleaners on lamps or fixtures, as the lacquer on the outside of the brass may be damaged as a result.

Enjoy your new Holtkötter lamp.




HOLTKÖTTER INTERNATIONAL, INC.

www.holtkoetter.com e-mail: customerservice@holtkoetter.com


Install the Bulbs and Shades

Step 1.



Loosen the set screw with the allen wrench (D). Then unscrew the aluminum ring (B) from the lamp arm. Remove one of the large washers (E).

Step 2.



Note: the shade is shipped with the handle in place. Prior to installation of the shade, remove the handle, the small plastic nut and the small plastic washer. These will be reinstalled after installing the bulb and glass shield.

Slide the shade (A) over the socket. Place the large washer (E) that was removed in Step 1 back onto the socket. Slide the aluminum ring (B) back onto the socket until it is tight.

Step 3.




Using the allen wrench (D), tighten the set screw on the aluminum ring into place.

DO NOT OVERTIGHTEN. MAKE SURE THE SHADE IS STILL LOOSE ENOUGH TO TURN.

ASSEMBLY INSTRUCTIONS FOR

Halogen Floor Lamp 6451/2


Step 4.



Put the 100-Watt halogen bulb (I) into the socket. Hold the bulb at the porcelain grip, push it down slightly and turn it clockwise.

BE CAREFUL NOT TO TOUCH THE BULB ENVELOPE WITH YOUR BARE HANDS.


Step 5.



Note: the small plastic nut and small plastic washer that were removed in Step 2 will be needed for this step.

Align the glass shield (C) with the small screw extending from the bottom of the shade. Place the small washer (G) and the small plastic nut (H) over the screw and finger tighten.

Step 6.



Note: the handle that was removed in Step 2 will be needed for this step.

Next, screw on the handle (F) and finger tighten.

DO NOT OVERTIGHTEN – THE GLASS SHIELD MAY CRACK
UNDER TOO MUCH PRESSURE.

Step 7.

Repeat steps 1-6 on the second arm of the lamp. Plug the lamp cord into the wall outlet. Your lamp is now operational.