


ASSEMBLY INSTRUCTIONS

Carefully unpack all lamp parts from the carton.

1. Take the lamp carefully out of the carton ,and place it on a flat surface.
2. Thread Part A onto the Base and clockwise to tighten .
3. Thread the Part B onto the Part A. Turn clockwise to tighten.
4. Thread the Part C onto the Part B. Turn clockwise to tighten.
5. Thread the Part D onto the Part C. Turn clockwise to tighten .
6. Thread the top of the central pipe onto the bottom of **PartD**.
7. Place the **Harp** onto the **Harp Base** .
8. Put the **Finial Disk** onto the **Shade** then tighten with **Finial**.
9. Use 3-WAY 150W TYPE A bulb (not included).



IMPORTANT SAFETY INSTRUCTIONS

This portable lamp has a polarized plug (one blade is wider than the other) as a safety feature to reduce the risk of electric shock.

This plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Never use with an extension cord unless plug can be fully inserted. Do not attempt to defeat this safety feature.